



HOW TO OPERATE INOX CLASPS

DOUBLE PRESS

1. Locate the clasp on your bracelet. Double press bracelet clasps have two small buttons on either side of the clasp that need to be pressed simultaneously to release the clasp.
2. Hold the bracelet securely with one hand and locate the buttons on the clasp with the other hand.
3. Place your thumb on one button and your forefinger on the other button. Apply gentle pressure to both buttons at the same time. You should hear a faint click as the clasp releases.
4. While still pressing the buttons, gently pull the two ends of the bracelet apart to fully open the clasp.
5. To close the clasp, simply push the two ends of the bracelet back together until you hear a click indicating that the clasp is secure.
6. Make sure the clasp is fully closed and secure before wearing your bracelet.



ANCHOR LOOP TOGGLE

1. Identify the toggle and loop on your bracelet. The toggle is the anchor-shaped component, while the loop is the circular component.
2. Hold the bracelet with one hand and use your other hand to grip the toggle.
3. Gently pull the toggle away from the loop. The loop should start to open up slightly.
4. Once the loop has opened up enough, slide the toggle through the loop.
5. Once the toggle is through the loop, release the toggle, and it should naturally fall back into its original position, securing the bracelet in place.
6. To remove the bracelet, simply follow the same steps in reverse: grip the toggle, pull it away from the loop, and slide it out of the loop.





HOW TO OPERATE INOX CLASPS

FOLD OVER

1. Identify the clasp: Look for the fold-over clasp on your bracelet. It is a type of clasp that folds over itself to secure the bracelet on your wrist.
2. Locate the opening: Find the opening on one side of the fold-over clasp. This is the part where you will insert your finger or a tool to release the clasp.
3. Insert a tool: If you don't want to use your fingers, you can use a small, pointed object like a paper clip or a pin to release the clasp. Insert the tool into the opening and gently lift the clasp.
4. Push the clasp: Once you have lifted the clasp, push it away from the opening with your fingers or the tool. This will release the clasp and allow you to open the bracelet.
5. Put on the bracelet: With the clasp open, place the bracelet on your wrist and close the clasp by pressing it down until it clicks into place.



INOX[®]
MEN'S JEWELRY

ARICCI MECHANICAL

1. Locate the clasp on your Aricci mechanical bracelet. The clasp is the metal piece that holds the two ends of the bracelet together.
2. Hold the bracelet with one hand and use your other hand to hold the clasp.
3. Look for the small metal piece on the side of the clasp. This is the locking mechanism that holds the clasp closed.
4. Use your fingernail or a small tool, such as a toothpick, to push the metal piece up.
5. While holding the metal piece up, use your other hand to gently pull the two ends of the bracelet apart.
6. The clasp should now be open, allowing you to put on or take off the bracelet.
7. To close the clasp, simply push the two ends of the bracelet together until you hear a click.
8. Make sure the metal piece on the side of the clasp snaps back into place, indicating that the clasp is securely closed.





HOW TO OPERATE INOX CLASPS



MAGNETIC OVERLAP

1. Using both hands, grasp each side of the clasp with your thumb and forefingers.
2. Using gentle pressure, slide the clasp apart in an up/down motion until the bracelet is fully open.
3. To close, reverse the steps above.



SLIDE MAGNETIC



TABULAR PRESS



HOOP LOOP

